


**INLINE MIXED-FLOW FANS  
VENTS TT SERIES**

**USER'S MANUAL**



[www.ventilation-system.com](http://www.ventilation-system.com)



**2011**



Read this manual carefully before installation and commissioning of the unit.

**READ THE INSTRUCTIONS CAREFULLY TO REDUCE THE RISK OF FIRE, ELECTRIC SHOCK OR INJURY.**

**WARNING** Compliance with the manual requirements ensures reliable fan operation throughout the entire service life.

This user's manual contains technical and operating logic description, mounting requirements, servicing and maintenance guidelines for the inline mixed-flow fans TT designed for supply or exhaust ventilation of premises heated during winter time.

The fans are made of plastic.

The delivery set includes:

1. Fan - 1 pce;
2. Screws and dowels - 4 pcs;
3. User's manual;
4. Packing box.

The fans are powered by AC 220-240V, 50-60 Hz single phase current and designed for continuous operation always connected to the electric mains.

Ingress protection rating IP X4.

The fans are designed for operation at the temperature range from +0°C up to +40°C. The air temperature in the ventilation system must not exceed +45°C.

Store the fan in manufacturer's packaging in a ventilated room at temperatures between +5°C and +40°C and relative humidity not more than 80% at +25°C.

The fans are suitable for connection to 100, 125, 150, 160, 200, 250, 315 mm air ducts.

The "S" index fan modifications are equipped with a high-power motor.

Air flow direction should match the direction of the arrow on the fan casing.

The fans are designed both for horizontal or vertical installation and are suitable for individual installation of one unit (fig. 2) or two or more units mounted in series or in parallel (fig.3).

The mounting kit components are delivered upon request. An air duct at least 1 meter long must be connected to the intake flange in case of horizontal fan mounting; a cowl must be installed in case of vertical mounting.

The intake flange must always be connected to an air duct.

Mounting sequence is shown in fig. 4-11.


The wiring diagrams are shown in fig. 12-16.

Designations:

QF - automatic circuit breaker (fig. 1);

S - external switch (fig. 1);

X - input terminal.



*Due to the constant improvements the design of some models may slightly differ from those described in this manual.*

Any electric connections, adjustment, servicing and repair works are allowed only after the unit is disconnected from power mains.

Mounting and maintenance are allowed for duly qualified electricians with valid electrical work permit.

The single-phase power grid must comply with the acting local electrical norms and standards. The fixed electrical wiring must be equipped with an automatic circuit breaker. The fan must be connected to the power grid through the automatic circuit breaker QF. The gap between the breaker contacts on all poles must be not less than 3 mm.

The overcurrent value shall be equal to the fan current consumption and is indicated on the fan rating plate.

Before installation check the fan for any visible damages of impeller and casing. The casing internals must be free of any foreign objects which can damage the impeller blades. Misuse of the device or any unauthorized modifications are not allowed.

The unit is not to be used by children and persons with reduced physical, mental or sensory capacities, without proper practical experience or expertise, unless they are controlled or instructed on the unit operation by the person(s) responsible for their safety. Do not leave the children unattended to avoid their playing with the device.

Take steps to prevent ingress of smoke, carbon monoxide and other combustion products into the room through open chimney flues or other fire-protection devices.


Sufficient air supply must be provided for proper combustion and exhaust of gases through the flue (chimney) of fuel burning equipment to prevent backdrafting.

The transported air must not contain any dust or other solid impurities, sticky substances or fibrous materials.

Do not use the fan in the environment containing hazardous or explosive materials and vapors, i.e. spirits, gasoline, insecticides, etc.

Do not close or block the intake and exhaust vents not to disturb the natural air passage.

Do not sit or put objects on the unit.



***This product must be disposed separately after deadline scheduling.***

***Do not throw out this product with unsorted city waste.***

#### **WARRANTY**

While purchasing the unit the customer accepts the following warranty terms:

Manufacturer hereby guarantees normal operation of the unit for 60 months from the date of resale, subject to the compliance with transport, storage, mounting and operation rules. In case of warranty service need submit this user's manual with filled manufacturing date and sales receipt or any other ownership confirmation. The unit modification must match the model stated by the user's manual.

In case of non-submission of the sales receipt or any other ownership confirmation and confirmation of the sales date, warranty period is calculated from the production date. Failure to submit the above documents may result in refuse for free servicing of faulty equipment.

All the units and components belonging to the faulty unit and replaced within the warranty period shall be covered by the previous warranty period and general warranty conditions. Thus the warranty period is not extended for the replaced fan components.

In case of failure due to faulty equipment during warranty period, the consumer has the right to exchange it.

The accessories operated together with the unit, both included and not included into the delivery list as well as other equipment operating jointly with the unit shall not be covered by the warranty. No warranty for compatibility of the fans with other producers' goods.

Only manufacturing defects are covered by the warranty terms.

All the defects and faults resulting from mechanical effect during operation process or natural wear-and-tear shall not be covered by the warranty conditions.


The malfunctions caused by violence of operation, servicing and maintenance guidelines either by Customer or third parties or caused by unauthorized design modifications shall not be covered by warranty.

#### **NO LIABILITY FOR THE RELATED DAMAGES:**


The manufacturer is not responsible for any mechanical or physical damages resulting from the manual requirements violation, the unit misuse or gross mechanical effect.

The indirect damages such as re-installation or re-connection of the unit, direct or indirect losses etc related to the unit replacement shall not be indemnified. Mounting/dismantling, connection/disconnection and regulation of the unit shall not be covered by the warranty. The contractor in charge for quality of mounting, electric mounting and adjustment works shall be responsible for the warranty thereof.

In any case the indemnity amount shall not exceed the actually paid value for the defective unit price.




2




3


MOUNTING  
SEQUENCE




4




5




6




7




8



9




10




11

WIRING DIAGRAM FOR TT 100, TT 125 fan modifications




12

WIRING DIAGRAM FOR TT 125S, TT 150, TT 160 fan modifications




13

WIRING DIAGRAM FOR TT 200, TT 250, TT 315 fan modifications



14

WIRING DIAGRAM FOR TT 100T, TT125T, TT125ST, TT150T, TT160T, TT200T, TT250T, TT315T




15



16


#### FAN CONNECTION WITHOUT INTEGRATED TIMER

1. Power the unit off by turning the automatic circuit breaker QF to OFF position.
  2. Release the fixing screws of the terminal block and remove the cover (fig. 18).
  3. Release the retaining clip screws and remove the retaining clip (fig. 19).
  4. Route the electric cable to the terminal block through the sealed lead-in and fix the cable with a retaining clip and screws (fig. 20).
  5. Select the fan operation mode (maximum speed, medium speed, low speed or speed switch with external speed switch). Connect the cables to the input fan terminal block in compliance with the matching wiring diagram and terminal designation inside the terminal box.
  6. Install the terminal box cover and fix it with self-tapping screws (fig. 21).
  7. Switch the fan on by turning the automatic circuit breaker to ON position (fig. 22).
- The fan starts running at required speed in case of correct electrical connection.  
If the fan does not operate, troubleshoot the malfunction.



#### FAN CONNECTION WITH INTEGRATED TIMER

1. Follow all the described above actions, clause 1-4 for fan connection without integrated timer.
2. Connect the cables to the input fan terminal block in compliance with the matching wiring diagram and terminal designation inside the terminal box.
3. Adjust the timer operating time by means of rotating the potentiometer adjusting screws (fig. 23) clockwise to increase the delay time or counter-clockwise to decrease it.
4. Follow the described above actions, clause 6-7 for fan connection without integrated timer.



23




#### FAN MODIFICATION WITH POWER CORD

The "V" index fan modifications are equipped with a three speed switch.  
The "RV" index fan modification is equipped with a power cord with various plug types and integrated three speed switch.  
This fan modification does not require any mounting operations for connection.

The built-in speed switch provides three fan air capacity modes:  
0 - fan is off  
I - low speed operation  
II - maximum speed operation

**The "V" and "RV" fan modifications do not include timer modification.**



### FANS WITH TEMPERATURE AND SPEED CONTROLLER MODULE TSC

The TT U fans (fig. 25) enable automatic impeller speed (air flow) control depending on the air temperature in the duct.

The "n" index models are equipped with a remote temperature sensor on a 4 m extension cable.

All the fan models with TSC module are equipped with a power cable.

The front panel has the following control knobs:

- pre-set impeller speed;
- thermostat operating threshold;

The yellow light indicator on the front panel shows thermostat operation.

#### Timer Operation Algorithm

Set the desired thermostat temperature (operating threshold) by turning the thermostat control knob.

Set the desired impeller speed (air flow) by turning the impeller speed control knob.

On reaching the pre-set air temperature and exceeding the thermostat operating threshold the fan motor switches to the maximum speed (maximum air flow).

The fan motor switches to the pre-set speed as the temperature drops below the pre-set thermostat operating threshold.

The switching delay function is provided to prevent frequent fan speed changes due to crossing the temperature threshold, especially if the operating temperature is equal to the thermostat threshold value.

The switch-off delay operating logic has two versions:


#### TT U (Temperature sensor delay algorithm)

On exceeding the pre-set temperature 2°C above the thermostat operating threshold the fan motor switches to the maximum speed. The fan motor reverts to the pre-set speed as soon as the duct temperature drops 2°C below the thermostat operating threshold. This algorithm is used to maintain the desired temperature up to within 2°C.

The fan speed changes are rare in this case.

#### TT U1 (Timer delay algorithm)

On reaching the pre-set air temperature the motor switches to higher (maximum) speed and the delay timer starts the 5-minute countdown. The fan motor reverts to the previous speed not earlier than 5 minutes after the duct air temperature drops below the thermostat pre-set threshold. This algorithm is used to maintain the desired air temperature precisely. In this mode the fan motor changes its speed more frequent as compared to the temperature sensor delay mode but in any case the switching cycle does not exceed 5 minutes.



### MAINTENANCE

Maintenance (fig. 26-30) means periodic cleaning of the surfaces from dust and dirt.

The impeller blades require thorough cleaning every six months.

To clean the impeller blades detach the clamps, remove the casing and wipe the blades with warm water and mild detergent solution.

Avoid water dripping on the motor while cleaning the blades (fig. 31).

### MALFUNCTIONS AND TROUBLESHOOTING

1. Fan does not get started - broken electric circuit.


Check the cable connection to the terminal block.

2. Excessive noise during the fan operation - foreign objects inside the fan casing.

Dismantle the fan (fig. 26-29) and remove foreign objects.

3. Excessive vibration during the fan operation - loose fan connection to the wall or the wall is not rigid enough.

Check the fan connection.



**ACCEPTANCE INFORMATION**

TT 100	<input type="checkbox"/>	TT 100T	<input type="checkbox"/>
TT 125	<input type="checkbox"/>	TT 125T	<input type="checkbox"/>
TT 125S	<input type="checkbox"/>	TT 125ST	<input type="checkbox"/>
TT 150	<input type="checkbox"/>	TT 150T	<input type="checkbox"/>
TT 160	<input type="checkbox"/>	TT 160T	<input type="checkbox"/>
TT 200	<input type="checkbox"/>	TT 200T	<input type="checkbox"/>
TT 250	<input type="checkbox"/>	TT 250T	<input type="checkbox"/>
TT 315	<input type="checkbox"/>	TT 315T	<input type="checkbox"/>
TT 100V	<input type="checkbox"/>	TT 100RV	<input type="checkbox"/>
TT 125V	<input type="checkbox"/>	TT 125RV	<input type="checkbox"/>
TT 125SV	<input type="checkbox"/>	TT 125SRV	<input type="checkbox"/>
TT 150V	<input type="checkbox"/>	TT 150RV	<input type="checkbox"/>
TT 160V	<input type="checkbox"/>	TT 160RV	<input type="checkbox"/>
TT 200V	<input type="checkbox"/>	TT 200RV	<input type="checkbox"/>
TT 250V	<input type="checkbox"/>	TT 250RV	<input type="checkbox"/>
TT 315V	<input type="checkbox"/>	TT 315RV	<input type="checkbox"/>
TT 100U	<input type="checkbox"/>		
TT 125U	<input type="checkbox"/>		
TT 125SU	<input type="checkbox"/>		
TT 150U	<input type="checkbox"/>		
TT 160U	<input type="checkbox"/>	1 <input type="checkbox"/>	n <input type="checkbox"/>
TT 200U	<input type="checkbox"/>		
TT 250U	<input type="checkbox"/>		
TT 315U	<input type="checkbox"/>		

Fan is ready for using.

Acceptance stamp

Date of production

Sold  
(name of trade enterprise and stamp of the shop)

Date of sale